

Cantilever parasol 3×3 m and Ø 3,5 m with base

Scope of delivery of base plate package


1 × Base incl. adjustable feet

Instructions


First fix the screw-on sleeve to the adapter plate by using the hex screws and the washers, you will need the open-ended spanner for this.

Note

The swivel joint is included in the scope of delivery of the cantilever parasol.



Handling cantilever parasol



Scope of delivery of cantilever parasol package

1 × cantilever parasol, 1 × swivel joint, 2 × cylinder screw, 2 × Allen key, 1 × hand crank, 4 × hex screw, 4 × washer, 1 × open-ended spanner

Assembly

Place the parasol on the adapter plate (the parasol must be on the same side as the foot pedal). Attach the parasol pole to the adapter plate using the cylinder screws. The hand crank is fitted onto the pin and tightened using the Allen key.

Open parasol

1. Slightly loosen the retaining screw at the parasol pole
2. Crank to open the parasol canopy. The locking slide automatically moves up
3. You can now use the locking slide to manually adjust the parasol to the desired angle. Finally fix it with the retaining screw
4. You can rotate the parasol 360° by pressing the step pedal

Note

When the parasol is closed, tie only the canopy (without the pole) with the tie straps.